

HAND TOOL FOR BLIND RIVETS

USER MANUAL

E-500RH-R



Ø**3.0**mm



max.

Ø**4.8**mm













OPERATION


Capacities: Ø3.0 à 4.8 mm (4.8mm for aluminium and steel only)

Weight: 0.7 kg






SETTING











UNINSTALLATION OF JAW

1.SCREW OFF THE JAW WITH THE WRENCH



2.SCREW ON THE NEW JAW WITH THE WRENCH

